

Black Decker Rice Cooker Manual

Este producto puede variar ligeramente del que aparece ilustrado.

1. Mango de la tapa
2. Tapa de vidrio templado con escape de vapor (Pieza N° RC3406-01)
3. Divisor de la cesta de vaporizar (Pieza N° RC3406-06)
4. Cesta de vaporizar (Pieza N° RC3406-05)
5. Olla de cocinar con marcas del nivel de agua (adentro) (Pieza N° RC3406-02)
6. Asas laterales frescas al tacto
7. Luz indicadora del ciclo de cocción
8. Luz indicadora del ciclo de calor
9. Interruptor de funcionamiento
10. Medidor de arroz (Pieza N° RC3406-03)
11. Cuchara de servir (Pieza N° RC3406-04)
- † Remplazable/removable por el consumidor



Como usar

Este aparato es solamente para uso doméstico.

PASOS PRELIMINARES

- Retire el material de empaque y toda calcamán adherida al producto.
- Retire y conserve toda literatura incluida con el producto.
- Lave y seque todas las piezas removibles, según las instrucciones de CUIDADO Y LIMPIEZA de este manual.
- Coloque el aparato sobre una superficie plana y estable.

COMO COCINAR EL ARROZ

1. Use el medidor de arroz provisto, para ajustar la cantidad de arroz que desea preparar; no use una taza corriente de medir. El medidor provisto acepta 2/3 taza de arroz crudo, aproximadamente 150 g (5 oz). Esta olla arrocerá acepta un máximo de 3 medidas de arroz crudo, proporcionando 6 tazas de arroz cocido.

2. Vierta el arroz en la olla de cocinar.

Nota: Para cocer el arroz, use solamente la olla de cocinar provista con este aparato.

3. Use las marcas del nivel de llenado en el interior de la olla como guías para medir el agua necesaria, según la cantidad de arroz que desea preparar. Por ejemplo, para 1 medida de arroz crudo, vierta agua hasta la marca que indica 1 taza. Para evitar que el contenido de la olla se desborde, asegúrese de no exceder la cantidad de agua.

4. Agregue manteca o aceite y sazón al gusto.

Nota: La primera vez que prepare arroz, consulte la guía en la página 14. Para un arroz más suave y sabroso, agregue más agua; para arroz de consistencia más firme, agregue menos agua.

5. Antes de colocar la olla de cocinar dentro de la amocera, asegúrese que la placa de calentamiento y la superficie exterior de la olla de cocinar estén limpias y secas. No permita que caigan granos de arroz ni demás alimentos adentro de la amocera.

6. Inserte la olla de cocinar adentro de la amocera.

7. Coloque la tapa de vidrio sobre la olla de cocinar. Para mejores resultados, la olla debe permanecer cubierta con la tapa de vidrio mientras el aparato está en funcionamiento.

Nota: Mientras el aparato está en funcionamiento, el escape de la tapa emite vapor. Coloque la tapa sobre la olla de cocinar, de manera que el escape permanezca alejado de los gabinetes y las paredes. Para evitar quemaduras, nunca acerque las manos al escape de vapor.

8. Desenrolle el cable y enchúfelo a una toma de corriente normal. La luz indicadora del ciclo de calor (KEEP WARM) se enciende.

9. Presione el interruptor de funcionamiento (ON). La luz indicadora del ciclo de cocción (COOK) se enciende y el aparato empieza a cocer el arroz.

10. Cuando el arroz está cocido, la luz indicadora del ciclo de cocción se apaga, el interruptor regresa a la posición normal, y la amocera para automáticamente al ciclo de calor. La luz indicadora del ciclo de calor (KEEP WARM) permanece encendida hasta que uno desconecta el aparato.

Nota: No trate de impedir que el aparato pase al ciclo de calor. No presione el interruptor (ON) después de que el aparato entre en funcionamiento.

11. Para mejor resultado, deje reposar el arroz por 15 minutos si desea cocerlo más tiempo. Si comen el arroz por más de 30 minutos, revuélvalo de vez en cuando para evitar que el arroz del fondo de la olla se dore.

12. Antes de servir, retire la tapa para mezclar el arroz. Use la cuchara provista con el aparato para evitar dañar la superficie antiañeche de la olla de cocinar.

Black+Decker rice cooker manual is an essential resource for anyone who owns a Black+Decker rice cooker. Understanding how to use this appliance effectively can greatly enhance your cooking experience, ensuring that you prepare perfectly cooked rice and other meals every time. This article will provide a comprehensive overview of the Black+Decker rice cooker, including its features, how to use it, and tips for maintenance and troubleshooting.

Overview of Black+Decker Rice Cookers

Black+Decker is a renowned brand known for its high-quality kitchen appliances, including rice cookers. These cookers are designed to simplify the rice cooking process, making it easier for users to achieve fluffy, delicious rice without constant monitoring.

Key Features of Black+Decker Rice Cookers

When selecting a Black+Decker rice cooker, it's important to understand its key features:

1. Capacity: Black+Decker rice cookers come in various sizes, typically ranging from 3 to 20 cups of cooked rice, catering to different household sizes and cooking needs.
2. Automatic Cooking: Most models feature an automatic cooking function that switches to "keep warm" once the rice is done, preventing overcooking.
3. Multi-Functionality: Many rice cookers also allow you to steam vegetables, cook soups,

or prepare other grains like quinoa and oatmeal.

4. Non-Stick Pot: The non-stick inner pot ensures easy cleaning and prevents rice from sticking or burning.

5. Measuring Cup and Spoon: Most models come with a measuring cup and a serving spoon, making it easier to measure rice and serve portions accurately.

Using Your Black+Decker Rice Cooker

To get the most out of your Black+Decker rice cooker, it's crucial to follow the instructions provided in the manual. Here's a general guide on how to use the cooker effectively:

Step-by-Step Instructions

1. Preparation:

- Measure the desired amount of rice using the provided measuring cup.
- Rinse the rice under cold water until the water runs clear. This helps remove excess starch and prevents the rice from being gummy.

2. Adding Ingredients:

- Place the rinsed rice in the non-stick pot.
- Add the appropriate amount of water, following the ratio indicated in the manual (usually 1:2 for white rice).
- For added flavor, consider adding a pinch of salt or a splash of oil.

3. Cooking:

- Close the lid securely.
- Plug in the rice cooker and select the cooking function. Most models have a simple toggle switch or button for this purpose.
- Wait for the cooking cycle to complete. The cooker will automatically switch to "keep warm" mode once the rice is done.

4. Serving:

- Allow the rice to sit for about 10-15 minutes in the "keep warm" mode.
- Open the lid carefully, as steam will escape.
- Use the serving spoon to fluff the rice before serving.

Common Recipes for Your Rice Cooker

While rice is the primary focus of a rice cooker, it can be used to prepare various dishes. Here are a few popular recipes to try:

Steamed Vegetables

1. Ingredients:

- Fresh vegetables (broccoli, carrots, or green beans)
- Water

2. Instructions:

- Place the vegetables in the steaming tray if your model includes one.
- Add water to the bottom of the rice cooker.
- Close the lid and set to cook until the vegetables are tender.

Quinoa

1. Ingredients:

- 1 cup quinoa
- 2 cups water

2. Instructions:

- Rinse quinoa under cold water.
- Combine quinoa and water in the rice cooker.
- Cook as you would rice, following the same water-to-quinoa ratio.

Maintenance and Cleaning

To ensure the longevity of your Black+Decker rice cooker, regular maintenance and cleaning are essential.

Cleaning the Rice Cooker

1. Unplug the Cooker: Always ensure the rice cooker is unplugged and cooled before cleaning.
2. Remove the Non-Stick Pot: Take out the inner pot and wash it with warm soapy water. Avoid using abrasive cleaners or scouring pads to prevent scratching.
3. Wipe the Exterior: Clean the exterior of the cooker with a damp cloth. Do not immerse the base in water.
4. Dry Thoroughly: Ensure all components are completely dry before reassembling.

Regular Maintenance Tips

- Check the Power Cord: Regularly inspect the power cord for any signs of wear or damage.
- Calibrate If Necessary: If you notice consistent cooking issues, consult the manual for

calibration instructions.

- **Store Properly:** When not in use, store the rice cooker in a cool, dry place to prevent dust accumulation.

Troubleshooting Common Issues

Even with regular maintenance, you may encounter issues with your rice cooker. Here are some common problems and their solutions:

Problem: Rice is Under-Cooked

- **Solution:** Ensure you're using the correct water-to-rice ratio. If necessary, add a little more water and continue cooking.

Problem: Rice is Overcooked or Burnt

- **Solution:** Check that the lid is closed properly during cooking. Also, consider reducing the cooking time or adjusting the water ratio.

Problem: Cooker Won't Turn On

- **Solution:** Ensure the cooker is plugged in and check the power source. If the issue persists, consult the manual for troubleshooting steps.

Conclusion

The **Black+Decker rice cooker manual** is a valuable tool for anyone looking to maximize their rice cooking experience. By understanding the features, following proper usage instructions, and maintaining your cooker, you can enjoy perfectly cooked rice and a variety of other dishes. Whether you're a novice cook or an experienced chef, a Black+Decker rice cooker can be an excellent addition to your kitchen arsenal, simplifying meal preparation and enhancing your culinary creations.

Frequently Asked Questions

Where can I find the manual for my Black & Decker rice

cooker?

You can find the manual for your Black & Decker rice cooker on the official Black & Decker website under the support or product manual section, or you can search for it using the model number of your cooker.

What is the best way to clean my Black & Decker rice cooker?

To clean your Black & Decker rice cooker, unplug it and allow it to cool. Remove the inner pot and wash it with warm soapy water. Wipe the exterior and the lid with a damp cloth. Avoid using abrasive cleaners or scouring pads.

How do I use the delay timer feature on my Black & Decker rice cooker?

To use the delay timer feature, add your ingredients and water to the inner pot, select the cooking program, then set the timer for when you want the rice to start cooking. Ensure the cooker is plugged in and follow the specific instructions provided in the manual for your model.

What types of rice can I cook in my Black & Decker rice cooker?

You can cook various types of rice in your Black & Decker rice cooker, including white rice, brown rice, jasmine rice, basmati rice, and even quinoa. Be sure to check the manual for specific water-to-rice ratios for each type.

Why is my Black & Decker rice cooker not turning on?

If your Black & Decker rice cooker is not turning on, check that it is properly plugged into a working outlet, ensure the inner pot is seated correctly, and make sure the lid is closed properly. If it still doesn't work, consult the manual for troubleshooting steps.

Can I use my Black & Decker rice cooker for steaming vegetables?

Yes, many Black & Decker rice cookers come with a steaming tray that allows you to steam vegetables while cooking rice at the same time. Refer to your manual for specific instructions on how to use the steaming function.

What should I do if my rice is undercooked in the Black & Decker rice cooker?

If your rice is undercooked, add a small amount of water (about 1/4 cup), close the lid, and let it cook for an additional 5-10 minutes. Check periodically to avoid overcooking, and consult the manual for recommended cooking times.

<https://soc.up.edu.ph/07-post/files?trackid=RIN17-8167&title=aruza-marketing-pyramid-scheme.pdf>

BLACK+DECKER

Register your products | BLACK+DECKER

BLACK+DECKER

[illegible]

...

Official website of BLACK+DECKER™. See our power tools, garden tools, and more. Find information on products, where to buy, news, and customer service.

Holding up to 550lbs, the BLACK+DECKER portable project center and vise is the perfect addition to your tool set. This workstation is multipurpose and helps you set up your project materials in ...

BLACK+DECKER dustbuster car vacuums are handy for cleaning in tight spaces. Lightweight and portable, these vacs will be a favorite car, truck, and vehicle accessory.

Find all your needed accessories and spare parts for BLACK+DECKER® appliances, tools and more here. Enjoy sanding discs, string trimmer line, circular saw parts, sawzall attachments, ...

Using a guide or tool to hang straight pictures ensures precision and alignment, preventing crooked displays and saving time on adjustments. Get organized with modular drawer units, ...

Official website of BLACK+DECKER™. See our power tools, garden tools, and more. Find information on products, where to buy, news, and customer service.

For the lawn enthusiast or perfectionist, BLACK+DECKER® offers gas or electric lawnmowers. Browse through our collection for electric, corded mowers.

HELP CENTER Welcome to the Black & Decker Help Center. Here, you can connect with us, engage

with fellow customers in our community section, and find answers to FAQs. We're ...

Register your products | BLACK+DECKER

Looking to register your products? Begin by starting an account on blackanddecker.com. Having an account on is like having a superpower for your BLACK+DECKER® tools and gadgets. You ...

BLACK+DECKER

...

Home | BLACK+DECKER

Official website of BLACK+DECKER™. See our power tools, garden tools, and more. Find information on products, where to buy, news, and customer service.

Workmate™ Portable Workbench, 425-To-550-Pound Capacity

Holding up to 550lbs, the BLACK+DECKER portable project center and vise is the perfect addition to your tool set. This workstation is multipurpose and helps you set up your project materials in ...

Car Vacuums | BLACK+DECKER

BLACK+DECKER dustbuster car vacuums are handy for cleaning in tight spaces. Lightweight and portable, these vacs will be a favorite car, truck, and vehicle accessory.

Accessories + Parts | BLACK+DECKER

Find all your needed accessories and spare parts for BLACK+DECKER® appliances, tools and more here. Enjoy sanding discs, string trimmer line, circular saw parts, sawzall attachments, ...

Electric Leaf Blowers | BLACK+DECKER

Using a guide or tool to hang straight pictures ensures precision and alignment, preventing crooked displays and saving time on adjustments. Get organized with modular drawer units, ...

Account | BLACK+DECKER

Official website of BLACK+DECKER™. See our power tools, garden tools, and more. Find information on products, where to buy, news, and customer service.

Electric Lawn Mowers | BLACK+DECKER

For the lawn enthusiast or perfectionist, BLACK+DECKER® offers gas or electric lawnmowers. Browse through our collection for electric, corded mowers.

Discover how to maximize your Black Decker rice cooker with our comprehensive manual. Get tips

[Back to Home](#)