

Bryant Furnace Installation Manual

Preferred™ Series

581J*14

Single Package Rooftop Gas Heat/Electric Cooling Unit
with Puron® (R-410A) Refrigerant



Installation Instructions

581J units for installation in the United States contain use of Bryant's 2-speed indoor fan control system. This complies with the U.S. Department of Energy (DOE) efficiency standard of 2018.
581J units for installation outside the United States may or may not contain use of the 2-speed indoor fan control system as they are not required to comply with the U.S. Department of Energy (DOE) efficiency standard of 2018.
For specific details on operation of the Bryant 2-speed indoor fan system, refer to the Variable Frequency Drive (VFD) Factory-Installed Option 2-Speed Fan Motor Control Installation, Setup, and Troubleshooting manual.

CONTENTS

SAFETY CONSIDERATIONS	1
General	3
Rated Indoor Airflow (cfm)	3
INSTALLATION	6
Jobsite Survey	6
Step 1 — Plan for Unit Location	6
• ROOF MOUNT	
Step 2 — Plan for Sequence of Unit Installation	6
• CURB-MOUNTED INSTALLATION	
• PAD-MOUNTED INSTALLATION	
• FRAME-MOUNTED INSTALLATION	
Step 3 — Inspect Unit	7
Step 4 — Provide Unit Support	7
• ROOF CURB MOUNT	
• SLAB MOUNT (HORIZONTAL UNITS ONLY)	
• ALTERNATE UNIT SUPPORT (IN LIEU OF CURB OR SLAB MOUNT)	
Step 5 — Field Fabricate Ductwork	9
Step 6 — Rig and Place Unit	9
• POSITIONING ON CURB	
Step 7 — Convert to Horizontal and Connect Ductwork (When Required)	10
Step 8 — Install Outside Air Hood	11
• ECONOMIZER HOOD REMOVAL AND SETUP — FACTORY OPTION	
• TWO POSITION DAMPER HOOD REMOVAL AND SETUP — FACTORY OPTION	
• ECONOMIZER HOOD AND TWO-POSITION HOOD	
Step 9 — Install Flue Hood	13
Step 10 — Install Gas Piping	13
• FACTORY OPTION THRU-BASE CONNECTIONS (GAS CONNECTION)	
Step 11 — Install External Condensate Trap and Line	16
Step 12 — Make Electrical Connections	16
• FIELD POWER SUPPLY	
• ALL UNITS	
• UNITS WITHOUT FACTORY-INSTALLED NON-FUSED DISCONNECT OR HACR CIRCUIT BREAKER	
• UNITS WITH FACTORY-INSTALLED NON-FUSED DISCONNECT	
• CONVENIENCE OUTLETS	
• FACTORY OPTION THRU-BASE CONNECTIONS (ELECTRICAL CONNECTIONS)	
• UNITS WITHOUT THRU-BASE CONNECTIONS	
• FIELD CONTROL WIRING	
• THERMOSTAT	
• UNIT WITHOUT THRU-BASE CONNECTION KIT	
Perfect Humidity™ System Control Connections	22
• PERFECT HUMIDITY — SPACE RH CONTROLLER	


• HEAT ANTICIPATOR SETTINGS	
Wiring Diagrams	22
EconoMiser® X (Factory Option)	27
• SYSTEM COMPONENTS	
• SPECIFICATIONS	
• INPUTS	
• OUTPUTS	
• ENVIRONMENTAL	
• ECONOMIZER MODULE WIRING DETAILS	
• INTERFACE OVERVIEW	
• SETUP AND CONFIGURATION	
• ENTHALPY SETTINGS	
• TWO-SPEED FAN OPERATION	
• CHECKOUT	
• TROUBLESHOOTING	
Low Ambient Control (Factory Option)	40
2-Speed Indoor Fan Motor System with Variable Frequency Drive (Factory Option)	40
RTU Open Control System	40
Smoke Detectors	40
• ADDITIONAL APPLICATION DATA	
Step 13 — Adjust Factory-Installed Options	41
• SMOKE DETECTORS	
• ECONOMIZER IV OCCUPANCY SWITCH	
Step 14 — Install Accessories	41
Step 15 — Check Belt Tension	41
• BELT FORCE — DEFLECTION METHOD	
• BELT TENSION METHOD	
Pre-Start and Start-Up	42
START-UP CHECKLIST	CL-1

SAFETY CONSIDERATIONS

Installation and servicing of air-conditioning equipment can be hazardous due to system pressure and electrical components. Only trained and qualified service personnel should install, repair, or service air-conditioning equipment.

Untrained personnel can perform basic maintenance functions of cleaning coils and filters and replacing filters. All other operations should be performed by trained service personnel. When working on air-conditioning equipment, observe precautions in the literature, tags and labels attached to the unit, and other safety precautions that may apply.

Follow all safety codes, including ANSI (American National Standards Institute) Z223.1. Wear safety glasses and work gloves. Use quenching cloth for unbrazing operations. Have fire extinguisher available for all brazing operations.

It is important to recognize safety information. This is the safety-alert symbol . When you see this symbol on the unit and in instructions or manuals, be alert to the potential for personal injury.

Manufacturer reserves the right to discontinue, or change at any time, specifications or designs without notice and without incurring obligations.
Catalog No. 04-03581014-01 Printed in U.S.A. Form 0581J-14-04 Pg 1 7-19 Replaces: 0581J-14-03

Bryant furnace installation manual is an essential resource for homeowners and HVAC professionals alike. Proper installation of a Bryant furnace ensures optimal performance, efficiency, and longevity. This article will provide a comprehensive overview of the key steps and considerations involved in the installation process, as well as important safety tips and maintenance practices to keep your furnace running smoothly.

Understanding Your Bryant Furnace

Before diving into the installation process, it's crucial to understand the basic components and features of your Bryant furnace.

Types of Bryant Furnaces

Bryant offers a variety of furnace types, including:

1. Gas Furnaces: These are the most common and utilize natural gas or propane as fuel.
2. Electric Furnaces: These furnaces use electric heating elements to generate heat.
3. Oil Furnaces: Less common, oil furnaces burn heating oil for warmth.

Key Components of a Bryant Furnace

Understanding the key components of your furnace will help during the installation process:

- Heat Exchanger: The component where heat is transferred from the combustion process to the air.
- Blower Motor: Responsible for circulating warm air throughout your home.
- Thermostat: Controls the temperature settings for the furnace.
- Ventilation System: Removes exhaust gases and brings in fresh air.
- Filter: Traps dust and debris to maintain indoor air quality.

Preparing for Installation

Before installation, proper preparation is essential to ensure a smooth process.

Tools and Materials Needed

Gather the following tools and materials:

- Screwdrivers (flathead and Phillips)
- Wrench set
- Level
- Tape measure
- Duct tape
- Electrical tape
- Safety goggles and gloves
- Manual for your specific Bryant furnace model
- Venting materials (if applicable)
- Gas line fittings (if applicable)

Safety Precautions

Safety is paramount during the installation of your Bryant furnace. Consider the following precautions:

- Turn off all power and gas supplies before starting the installation.

- Wear appropriate personal protective equipment, such as gloves and goggles.
- Ensure proper ventilation in the installation area.
- Familiarize yourself with local building codes and regulations.
- If you are not comfortable with gas connections, hire a qualified technician.

Installation Steps

The installation of your Bryant furnace can be broken down into several key steps:

Step 1: Choosing the Right Location

Selecting the right location for your furnace is crucial for efficiency and safety. Consider the following:

- Accessibility: Ensure the furnace is easily accessible for maintenance and repairs.
- Ventilation: The area should allow for proper ventilation of combustion gases.
- Distance from Flammable Materials: Maintain adequate distance from flammable items and materials.
- Space for Ductwork: Ensure there is enough space for ductwork and air circulation.

Step 2: Preparing the Area

1. Clear the installation area of any debris or obstacles.
2. Check the structural integrity of the floor and ensure it can support the furnace's weight.
3. Mark the location for the furnace, ductwork, and venting system.

Step 3: Installing the Furnace

1. Position the Furnace: Carefully position the furnace in the chosen location, ensuring it is level.
2. Secure the Furnace: Use brackets or screws to secure the furnace in place.
3. Connect the Ductwork:
 - Attach the supply and return ductwork to the furnace.
 - Use duct tape to seal all joints to prevent air leaks.
4. Install the Venting System:
 - Connect the vent pipe to the furnace and ensure it leads outside.
 - Use appropriate materials to seal the venting system.

Step 4: Making Electrical Connections

1. Power Supply: Connect the furnace to the electrical supply according to the manufacturer's instructions.
2. Thermostat Wiring: Follow the wiring diagram provided in the installation manual to connect the

thermostat.

Step 5: Connecting the Gas Line (if applicable)

1. Gas Supply Line: Connect the gas line to the furnace using appropriate fittings.
2. Test for Leaks: Use a gas leak detection solution to check for leaks at the connections.
3. Turn on the Gas Supply: Once confirmed no leaks are present, turn on the gas supply.

Step 6: Initial Startup and Testing

1. Power On: Turn on the power supply to the furnace.
2. Thermostat Settings: Set the thermostat to the desired temperature.
3. Observe Operation: Monitor the furnace during its first cycle to ensure it operates correctly.
4. Check for Unusual Noises: Listen for any unusual sounds that may indicate issues.

Post-Installation Maintenance

Once your Bryant furnace is installed, regular maintenance is vital to ensure its longevity and efficiency.

Regular Maintenance Tasks

1. Change the Filter: Replace or clean the air filter every 1-3 months, depending on usage.
2. Inspect Ductwork: Regularly check for leaks or blockages in the ductwork.
3. Schedule Professional Inspections: Have a qualified technician inspect your furnace annually.
4. Clean the Furnace: Dust and debris can accumulate; clean the exterior and accessible components regularly.

Signs of Potential Issues

Be vigilant for signs that your furnace may need repairs:

- Unusual noises (clanging, banging, or rattling)
- Inconsistent heating throughout your home
- Increased energy bills without a change in usage
- Yellow flame in the burner instead of blue
- Frequent cycling on and off

Conclusion

The Bryant furnace installation manual is a valuable tool for ensuring that your furnace operates efficiently and effectively. By following the outlined steps and safety precautions, you can successfully install your Bryant furnace and enjoy a warm, comfortable home. Remember to keep up with regular maintenance and consult a professional when needed to extend the life of your furnace and maintain its performance. Whether you're a DIY enthusiast or hiring a professional, understanding the installation process empowers you to make informed decisions about your heating system.

Frequently Asked Questions

What is the first step in the Bryant furnace installation process?

The first step is to read through the Bryant furnace installation manual thoroughly to understand the specific requirements and safety precautions before beginning the installation.

Are there any specific tools required for installing a Bryant furnace?

Yes, the installation manual lists essential tools such as a screwdriver, adjustable wrench, level, and voltage tester that are necessary for a successful installation.

How do I determine the correct size of the Bryant furnace for my home?

To determine the correct size, refer to the manual for guidelines on calculating the heating load based on your home's square footage, insulation, and climate zone.

What are the ventilation requirements mentioned in the Bryant furnace installation manual?

The manual outlines specific ventilation requirements, including the need for proper air intake and exhaust systems to ensure safe and efficient operation of the furnace.

Is it necessary to hire a professional for the installation of a Bryant furnace?

While some experienced DIYers may install it themselves, the manual recommends hiring a licensed HVAC professional to ensure compliance with local codes and safety standards.

What safety precautions should be taken during the installation of a Bryant furnace?

Safety precautions include turning off power to the unit, using personal protective equipment, ensuring proper gas connections, and following all guidelines outlined in the installation manual.

Where can I find the Bryant furnace installation manual if I lost my copy?

You can find the Bryant furnace installation manual on the official Bryant website under the 'Customer Support' or 'Product Manuals' section, or by contacting their customer service for assistance.

Find other PDF article:

<https://soc.up.edu.ph/20-pitch/files?ID=spb37-3878&title=equinix-threat-analysis-center.pdf>

[Bryant Furnace Installation Manual](#)

Air Conditioners, Furnaces, Heating & Cooling | Bryant

Bryant Heating & Cooling offers heating and air conditioning systems to meet your needs. Learn more about our products and find a dealer near you.

37MGRA | Ductless Mini Split | Bryant

Discover the features and benefits of the 37MGRA from Bryant. Trust Bryant Heating and Cooling for all of your HVAC needs.

[248TAN | Heat Pump | Bryant](#)

Discover the features and benefits of the 248TAN from Bryant. Trust Bryant Heating and Cooling for all of your HVAC needs.

[134S | Air Conditioner | Bryant](#)

Discover the features and benefits of the 134s from Bryant. Trust Bryant Heating and Cooling for all of your HVAC needs.

Dual Fuel Heat Pump: A Complete Guide | Bryant

Bryant's dual fuel heat pumps integrate cutting-edge technology, providing consistent comfort and peace of mind. Explore how these systems work, their benefits, and determine if they are ideal ...

927T | Gas Furnace | Bryant

Discover the features and benefits of the 927T from Bryant. Trust Bryant Heating and Cooling for all of your HVAC needs.

[HVAC Cost | Replacement and Installation Costs | Bryant](#)

Whether you're replacing an outdated HVAC system or installing a new one, knowing the expenses involved with HVAC cost helps you make informed decisions. Learn more from Bryant.

HVAC Repair | Bryant

For reliable and efficient HVAC repair, trust Bryant. Your local Bryant dealer is trained to diagnose and repair all types of HVAC systems, ensuring your home remains comfortable throughout the ...

148TAN | Air Conditioner | Bryant

Explore the benefits of the 148TAN air conditioner. Trust Bryant for all of your HVAC needs.

HVAC Heating and Cooling Units | Bryant

Discover top-rated heating and cooling solutions for your home. From heating and air conditioning systems to energy-efficient HVAC heating and cooling units, find the best air conditioning and ...

[Air Conditioners, Furnaces, Heating & Cooling | Bryant](#)

Bryant Heating & Cooling offers heating and air conditioning systems to meet your needs. Learn more about our products and find a dealer near you.

37MGRA | Ductless Mini Split | Bryant

Discover the features and benefits of the 37MGRA from Bryant. Trust Bryant Heating and Cooling for all of your HVAC needs.

248TAN | Heat Pump | Bryant

Discover the features and benefits of the 248TAN from Bryant. Trust Bryant Heating and Cooling for all of your HVAC needs.

[134S | Air Conditioner | Bryant](#)

Discover the features and benefits of the 134s from Bryant. Trust Bryant Heating and Cooling for all of your HVAC needs.

Dual Fuel Heat Pump: A Complete Guide | Bryant

Bryant's dual fuel heat pumps integrate cutting-edge technology, providing consistent comfort and peace of mind. Explore how these systems work, their benefits, and determine if they are ideal ...

[927T | Gas Furnace | Bryant](#)

Discover the features and benefits of the 927T from Bryant. Trust Bryant Heating and Cooling for all of your HVAC needs.

HVAC Cost | Replacement and Installation Costs | Bryant

Whether you're replacing an outdated HVAC system or installing a new one, knowing the expenses involved with HVAC cost helps you make informed decisions. Learn more from Bryant.

[HVAC Repair | Bryant](#)

For reliable and efficient HVAC repair, trust Bryant. Your local Bryant dealer is trained to diagnose and repair all types of HVAC systems, ensuring your home remains comfortable throughout ...

148TAN | Air Conditioner | Bryant

Explore the benefits of the 148TAN air conditioner. Trust Bryant for all of your HVAC needs.

HVAC Heating and Cooling Units | Bryant

Discover top-rated heating and cooling solutions for your home. From heating and air conditioning systems to energy-efficient HVAC heating and cooling units, find the best air conditioning and ...

Discover the essential Bryant furnace installation manual for step-by-step guidance. Ensure a smooth setup and optimal performance. Learn more today!

[Back to Home](#)