


# Rules Of Dimensioning In Engineering Drawing

Dimensioning rules:  
...more like guidelines.

---



1. Don't overdefine or underdefine the object. [MOST IMPORTANT]
2. Dimension to the visible contour or shape of the feature / Don't dimension to hidden lines.
3. Don't dimension to object lines (model edges), use extension lines.
4. Don't overlap a dimension and the model. Place dimensions away from the model's surface.
5. Don't cross extension lines if possible.
6. Group dimensions when possible unless it become difficult to read.
7. Place dimensions on the side of the view were adjacent views exist (for easy referencing).

Rules of dimensioning in engineering drawing are fundamental principles that guide engineers and designers in creating accurate, clear, and comprehensible technical drawings. These rules ensure that anyone who interprets the drawing can understand the dimensions, tolerances, and other critical specifications necessary for manufacturing and assembly. Following these rules not only enhances communication among stakeholders but also minimizes errors and misunderstandings during the production process. This article delves into the essential rules of dimensioning, the types of dimensions, and best practices to ensure clarity in engineering drawings.

## Understanding Dimensioning

Dimensioning is the process of defining the size, location, and geometry of a drawing. It plays a crucial role in engineering drawings, as it provides the necessary information to fabricate a component accurately. Without proper dimensioning, designs may be misinterpreted, leading to defects or failures in the final product.

## Importance of Dimensioning

- Clarity: Proper dimensioning helps convey the exact specifications needed for production.
- Standardization: Following established dimensioning rules promotes consistency across drawings, which is essential for collaborative projects.
- Error Reduction: Clear dimensions reduce the risk of mistakes during manufacturing and assembly.

- Legal and Compliance Issues: Accurate dimensions ensure that designs comply with industry standards and regulations.

## **General Rules of Dimensioning**

To create effective engineering drawings, there are several fundamental rules of dimensioning that engineers must adhere to:

### **1. Dimension Placement**

- Outside the Object: Dimensions should be placed outside the drawing, avoiding overlap with the actual object unless absolutely necessary.
- Aligned with Features: Dimension lines should be aligned with the features being measured to avoid ambiguity.
- Avoid Clutter: Limit the number of dimensions on a drawing to prevent confusion, ensuring that each dimension is essential.

### **2. Dimensioning Methods**

There are various methods of dimensioning that can be employed, including:

- Linear Dimensioning: Used for straight lines, where the dimension is shown as a horizontal or vertical line with a numerical value.
- Radial Dimensioning: Used for circles and arcs, indicating the radius or diameter.
- Angular Dimensioning: Used to specify angles between two lines or surfaces.

### **3. Consistency in Units**

- Single Unit System: All dimensions on a drawing should be in the same unit (e.g., all in millimeters or inches) to avoid confusion.
- Decimal or Fractional: Choose whether to use decimal or fractional dimensions based on industry standards or project requirements, but remain consistent throughout.

### **4. Dimension Tolerances**

- Specify Tolerances: Always include tolerances to define acceptable variations in dimensions.
- Use Symbols: Utilize standard symbols (e.g.,  $\pm$ ) to clearly indicate the type of tolerance being applied (e.g., unilateral, bilateral).

## 5. Avoiding Redundancy

- No Duplicate Dimensions: Avoid repeating the same dimension in multiple locations on a drawing.
- Reference Dimensions: Use reference dimensions sparingly and clearly indicate them to avoid confusion with actual measurements.

## Types of Dimensions

Understanding the different types of dimensions can help in effectively communicating the necessary information. Here are the primary types of dimensions used in engineering drawings:

### 1. Linear Dimensions

Linear dimensions are used to measure the length, width, or height of an object. They are typically represented as horizontal or vertical lines with dimension lines extending from the feature to the dimension itself.

### 2. Angular Dimensions

Angular dimensions specify the angle between two lines or surfaces. They are indicated with dimension lines extending from the vertex of the angle, along with the angle value.

### 3. Radial and Diameter Dimensions

- Radial Dimensions: Indicate the radius of arcs and circles.
- Diameter Dimensions: Specify the diameter of circular features.

### 4. Coordinate Dimensions

Coordinate dimensioning involves defining the location of points on a drawing using a coordinate system. This method is particularly useful for complex shapes and assemblies.

## Best Practices for Dimensioning

To ensure that dimensioning is clear and effective, consider adhering to the following best practices:

# 1. Use Clear Symbols and Abbreviations

- Standard Symbols: Employ universally recognized symbols to convey information quickly.
- Abbreviations: Use standard abbreviations for terms like "diameter" ( $\varnothing$ ) and "radius" (R) to save space and enhance clarity.

# 2. Maintain Readability

- Font Size: Use a font size that is legible when printed, ensuring that all text and numbers are easily readable.
- Line Weight: Differentiate between different types of lines (e.g., dimension lines, extension lines) using varying line weights.

# 3. Group Related Dimensions

Organizing dimensions logically can enhance clarity:

- Cluster Related Dimensions: Group dimensions that relate to the same feature together.
- Use Baseline Dimensioning: Establish a common reference point for related dimensions to simplify interpretation.

# 4. Verify Dimensions

Before finalizing a drawing, it is vital to double-check dimensions:

- Cross-Check: Verify all dimensions against the original design specifications.
- Peer Review: Have another engineer review the drawing to catch potential errors or ambiguities.

# Conclusion

In conclusion, the rules of dimensioning in engineering drawing play a pivotal role in ensuring that designs are accurately communicated and can be effectively manufactured. By adhering to established dimensioning practices, engineers can create clear, concise, and standardized drawings that facilitate collaboration and minimize errors. Understanding the importance of proper dimensioning, the various methods and types of dimensions, and following best practices will ultimately lead to more successful engineering projects and satisfied stakeholders. As the industry evolves, continual education on dimensioning practices will remain crucial for engineers and designers alike.

# Frequently Asked Questions

## What is dimensioning in engineering drawing?

Dimensioning in engineering drawing refers to the process of specifying the size, shape, and location of features on a drawing, using numerical values and symbols.

## What are the basic rules of dimensioning?

The basic rules of dimensioning include: 1) Use clear and concise dimensions, 2) Avoid redundant dimensions, 3) Place dimensions outside the object whenever possible, and 4) Use consistent units of measurement.

## Why is it important to avoid overlapping dimensions?

Avoiding overlapping dimensions is important because it prevents confusion, ensures clarity, and helps maintain readability of the drawing, allowing for accurate interpretation by engineers and manufacturers.

## How should dimensions be aligned in an engineering drawing?

Dimensions should be aligned vertically or horizontally, and should be placed parallel to the feature they describe. This enhances readability and minimizes misinterpretation.

## What is the significance of using appropriate dimensioning symbols?

Using appropriate dimensioning symbols is significant as it provides standardized information that helps in understanding the specifications quickly and accurately, ensuring that all parties interpret the drawing in the same manner.

## What are the differences between linear and angular dimensioning?

Linear dimensioning specifies the length or width of a feature using straight lines, while angular dimensioning specifies the angle between two lines or features, indicating rotational measurements.

## When should you use reference dimensions?

Reference dimensions should be used when you need to provide additional information that is not critical for manufacturing but may help in the assembly or inspection process, and should always be indicated by parentheses.

## What is the role of tolerance in dimensioning?

Tolerance in dimensioning defines the permissible variation in the size or location of a feature, ensuring that parts will fit together properly during assembly and function as intended.

Find other PDF article:

<https://soc.up.edu.ph/55-pitch/Book?trackid=cVo29-3471&title=sportsman-900-air-rifle-repair-manual.pdf>

## Rules Of Dimensioning In Engineering Drawing

game ready studio -  
game ready studio CUDA  
studio ...

**DFM** -  
Bingo Testing DFM DFM DFM 1. DFM DFM DFM Design for  
Manufacture ...

**403 forbidden** -  
Oct 1, 2022 · 403 “ 403 forbidden ” HTTP HTTP STATUS  
CODE ...

2025 visa  
VISA IC IC VISA  
...

-  
“according to Glossary of Unicode Terms, a writing system is a set of rules for using one scripts  
to write a particular language” ...

Définitions : règle - Dictionnaire de français Larousse  
règle - Définitions Français : Retrouvez la définition de règle, ainsi que les synonymes, expressions,  
citations... - synonymes, homonymes, difficultés, citations.

**2 rules** ...  
rules 2

**2025f1 “papaya rules”**  
papaya rules  
...

rule34? -  
Internet Rule #34

**rules-based international order**  
Mar 22, 2021 · rules-based international order  
...

game ready studio -  
game ready studio CUDA  
studio ...

Bingo Testing   DFM   DFM   DFM   1. DFM   DFM   DFM   Design for Manufacture ...

Oct 1, 2022 · 0000000000000000 00000000403 00000000 " 403 forbidden "000 HTTP 0000HTTP STATUS  
CODE0000000000000000 0 ...

000000000000 00000000000000000000VISA00000000000000000000IC00000000000000000000IC000000000000VISA000000 00000000  
 0000 ...

□□□□“according to Glossary of Unicode Terms, a writing system is a set of rules for using one scripts to write a particular language” □□□□□□□□□□ □□□□□□□□□□ ...

règle - Définitions Français : Retrouvez la définition de règle, ainsi que les synonymes, expressions, citations... - synonymes, homonymes, difficultés, citations.

rules2

papaya rules  
 ...

Internet Rule #34 "If you see it, it's true..."

Mar 22, 2021 · rules-based international order

...  
... ..

Unlock the essentials of the rules of dimensioning in engineering drawing. Master best practices for precision and clarity. Learn more in our comprehensive guide!

[Back to Home](#)