


Franklin Electric Submersible Pump Manual

**Franklin Electric**

**6" & 8" SUBMERSIBLE
TURBINE PUMPS
OWNER'S MANUAL**



BEFORE INSTALLING PUMP, BE SURE TO READ THIS OWNER'S MANUAL CAREFULLY.

CAUTION Mechanical shaft seals must not run dry. Fill pump with water before starting or pump will be damaged. The motor on this pump is guaranteed by the manufacturer and in event of failure it must be returned to an authorized service station for repairs. Motor warranty is void if repairs aren't made by an authorized repair station.

INSPECT THE SHIPMENT

Examine the pump when it is received to be sure there has been no damage in shipping. Should any be evident, report it immediately to the transportation company and ask to have it inspected. Check the pump and motor nameplate to ensure you have received the correct pump unit.

READ AND FOLLOW SAFETY INSTRUCTIONS

⚠ This is the safety alert symbol. When you see this symbol on your pump or in this manual, look for one of the following signal words and be alert to the potential for personal injury:

DANGER warns about hazards that will cause serious personal injury, death or major property damage if ignored.

WARNING warns about hazards that can cause serious personal injury, death or major property damage if ignored.

CAUTION warns about hazards that will or can cause minor personal injury or major property damage if ignored.

The label **NOTICE** indicates special instructions, which are important but not related to hazards.

WARNING Carefully read and follow all safety instructions in this manual and on pump.



Hazardous voltage. Can shock, burn, or cause death.

Ground pump before connecting to power supply. Disconnect power before working on pump, motor or tank.

Wire motor for correct voltage. See "Electrical" section of this manual and motor nameplate.

Ground motor before connecting to power supply.

⚠ Meet National Electrical Code, Canadian Electrical Code, and local codes for all wiring.

⚠ Follow wiring instructions in this manual when connecting motor to power lines.

Franklin Electric Submersible Pump Manual is an essential resource for anyone who owns or operates a submersible pump manufactured by Franklin Electric. These pumps are widely used in various applications, including residential, agricultural, and industrial settings, due to their reliability, efficiency, and versatility. Understanding the operation, maintenance, and troubleshooting of these pumps is crucial to ensuring their longevity and optimal performance. This article will provide a comprehensive overview of the Franklin Electric submersible pump manual, covering everything from pump selection to installation, operation, maintenance, and troubleshooting.

Overview of Franklin Electric Submersible Pumps

Franklin Electric is a leading manufacturer of submersible pumps, renowned for their high-quality products designed for various applications. Submersible pumps are designed to operate underwater, making them ideal for applications involving groundwater extraction, sewage pumping, and irrigation systems. The main types of Franklin Electric submersible pumps include:

- Deep Well Pumps: Typically used for extracting water from deep sources, these pumps are characterized by their robust design and efficiency.
- Effluent Pumps: Designed for transferring wastewater and effluent, these pumps are built to handle solid materials.
- Sump Pumps: Commonly used in residential basements, they prevent flooding by pumping excess water away from the foundation.

Choosing the Right Submersible Pump

Selecting the appropriate Franklin Electric submersible pump for your application is critical. Here are some factors to consider:

1. Application Requirements

- Determine the purpose of the pump (e.g., groundwater extraction, sewage removal, etc.).
- Assess the required flow rate (measured in gallons per minute, GPM) and head pressure (measured in feet).

2. Water Characteristics

- Analyze the quality of the water, including the presence of sediments, corrosive elements, and temperature.
- Identify whether the water is potable or non-potable.

3. Pump Specifications

- Review the pump's horsepower (HP) rating and efficiency.
- Check the material construction (e.g., stainless steel, plastic) based on the application environment.

Installation of Franklin Electric Submersible Pumps

Proper installation is crucial for the effective operation of submersible pumps. Below are key steps and considerations for installation:

1. Preparation

- Gather necessary tools and materials, including the pump, discharge pipe, wiring, and connectors.
- Review the installation manual specific to your pump model.

2. Site Assessment

- Ensure the installation site is suitable, considering factors like access to power supply and drainage.
- Conduct a site survey to determine the depth of the well or sump.

3. Pump Assembly

- Assemble the pump as per the manufacturer's guidelines.
- Attach the discharge pipe securely to prevent leaks.

4. Electrical Connections

- Follow electrical safety protocols when connecting the pump to the power supply.
- Use appropriate wire sizes and circuit breakers as outlined in the manual.

5. Lowering the Pump

- Carefully lower the pump into the well or sump using a rope or cable.
- Make sure the pump is positioned correctly to avoid damage or malfunction.

Operating Franklin Electric Submersible Pumps

Once the pump is installed, understanding how to operate it is essential for achieving optimal performance.

1. Initial Startup

- Before starting the pump, check all connections and ensure that the discharge valve is closed.
- Turn on the power supply and monitor for any unusual noises or vibrations.

2. Monitoring Performance

- Regularly check the flow rate and pressure to ensure they meet the desired specifications.
- Look for signs of wear or damage to the pump components.

3. Safety Precautions

- Always follow safety guidelines when operating the pump.
- Ensure that the power supply is properly grounded and protected with circuit breakers.

Maintenance of Submersible Pumps

Routine maintenance is essential to prolonging the lifespan and reliability of Franklin Electric submersible pumps. The following maintenance tasks should be performed regularly:

1. Visual Inspection

- Regularly inspect the pump and its components for signs of wear, corrosion, or damage.
- Check the discharge pipe for leaks or blockages.

2. Cleaning and Flushing

- Clean the pump and surrounding area to prevent debris buildup.
- Flush the pump with clean water to remove any sediments or contaminants.

3. Lubrication

- If applicable, lubricate the motor bearings according to the manual specifications.
- Ensure that the pump operates smoothly without excessive friction.

4. Electrical System Check

- Regularly inspect electrical connections for corrosion or wear.
- Test the circuit breaker and ensure proper operation of the electrical system.

Troubleshooting Common Issues

Even with proper installation and maintenance, issues can arise. Here are some common problems and their troubleshooting steps:

1. Pump Won't Start

- Check the power supply and ensure that the circuit breaker hasn't tripped.
- Inspect the electrical connections for damage or loose wires.

2. Low Flow Rate

- Examine the intake screen for blockages or debris.
- Verify that the pump is adequately submerged in water.

3. Unusual Noises

- Listen for grinding or rattling sounds, which may indicate wear or damage.
- Check for loose components or misalignment in the pump assembly.

4. Overheating

- Ensure the pump is not running dry, as this can lead to overheating.
- Confirm that the motor is receiving adequate ventilation.

Conclusion

The Franklin Electric submersible pump manual serves as an indispensable guide for users seeking to understand the intricacies of installation, operation, maintenance, and troubleshooting of their pumps. By following the guidelines outlined in the manual and adhering to best practices, users can ensure their pumps operate efficiently and effectively for years to come. Proper knowledge and care can lead to significant benefits, including reduced downtime and enhanced performance, making it essential for both novice and experienced pump operators alike.

Frequently Asked Questions

What is the purpose of the Franklin Electric

submersible pump manual?

The Franklin Electric submersible pump manual provides essential information on installation, operation, maintenance, and troubleshooting of submersible pumps manufactured by Franklin Electric.

Where can I find the latest Franklin Electric submersible pump manual?

The latest Franklin Electric submersible pump manual can be found on the official Franklin Electric website under the 'Support' or 'Resources' section, or by contacting their customer service.

What safety precautions should be taken when using the Franklin Electric submersible pump?

Safety precautions include ensuring the power supply is disconnected before installation or maintenance, using proper personal protective equipment, and following guidelines in the manual to avoid electrical hazards.

How often should I perform maintenance on my Franklin Electric submersible pump?

Maintenance should typically be performed annually, but the frequency may vary based on usage conditions. Refer to the manual for specific recommendations related to your model.

What are common troubleshooting steps in the Franklin Electric submersible pump manual?

Common troubleshooting steps include checking power supply, verifying that the pump is submerged, inspecting for blockages in the discharge line, and ensuring that the motor is functioning properly.

Can I download the Franklin Electric submersible pump manual in PDF format?

Yes, many Franklin Electric submersible pump manuals are available for download in PDF format on their official website, making it easy to access and reference.

Find other PDF article:

<https://soc.up.edu.ph/19-theme/files?trackid=xoe50-2332&title=eet-speech-therapy-goals.pdf>

[Franklin Electric Submersible Pump Manual](#)

Benjamin Franklin -

Benjamin Franklin 1706117—1790417
 ...

SCI -

SCI

SCI -

sci Taylor&Francis 16% ...

sci -

InVisor ~ SCI/SSCI SCOPUS CPCI/EI
ta invisitor003 ...

Franklin? -

May 18, 2019 · Franklin 2 dancer
 ...

SCI -

OA OA OA SinoScript SCI
IF ...

J Franklin I -

J Franklin I Journal Of The Franklin Institute-engineering And Applied
Mathematics ... 3

-

3 2 2 1917
Franklin C.McLean

-

2001 Boneh Franklin [2] Identity-Based Encryption IBE
p G_1 G_2, G_T

latex -

LeTeX IEEE

Benjamin Franklin -

Benjamin Franklin 1706117—1790417
 ...

SCI -

SCI

SCI -

sci Taylor&Francis 16% ...

sci -

InVisor~ SCI/SSCI SCOPUS CPCI/EI ...

Franklin? -

May 18, 2019 · Franklin2dancer

SCI -

OA OA OA SinoScript SCI IF ...

J Franklin I -

J Franklin I Journal Of The Franklin Institute-engineering And Applied Mathematics ... 3

-

3221917

-

2001BonehFranklin [2]Identity-Based Encryption IBE

latex -

LeTeX IEEE

Get the ultimate guide with the Franklin Electric submersible pump manual. Discover essential tips and troubleshooting techniques. Learn more to optimize your pump's performance!

[Back to Home](#)