

Lennox Air Handler Manual



RETAIN THESE INSTRUCTIONS
FOR FUTURE REFERENCE

⚠ WARNING

Due to higher operating pressures, CBWMV units must not be applied to steam boiler systems.

⚠ CAUTION

Unit is designed to be used with non-potable boiler systems only.

⚠ CAUTION

Physical contact with metal edges and corners while applying excessive force or rapid motion can result in personal injury. Be aware of, and use caution when working near these areas during installation or while servicing this equipment.

Introduction

The multi-positional Dave Lennox Signature™ Collection CBWMV air handler/hot water coil unit is designed to be used with non-potable boiler systems for warm air heating. A variety of Lennox air conditioning systems may be applied to the CBWMV unit for optional cooling.

INSTALLATION INSTRUCTIONS

CBWMV Series Units

AIR HANDLERS
505,047M
09/06
Supersedes 02/06

TTP Technical
Publications
Lubbock U.S.A.

Table of Contents

Introduction	1
Shipping & Packing List	1
CBWMV Unit Dimensions	2
General	3
CBWMV Unit Parts Arrangement	3
CBWMV Unit Parts Description	3
CBWMV Unit Optional Accessories	3
Requirements	4
Application	4
Installation - Setting Equipment	4
Duct System	5
Return Air Opening Guidelines	6
Filter Assembly & Filters	8
Plumbing	8
Electrical	8
FreezeStat Operation	12
BDC3 Variable Blower Control Board	12
Blower Speed Adjustments	12
Initial Air System Purging	16
System Adjustments	17
Annual Service	17
Service Filters	17
Winterizing the CBWMV Unit	17
Repair Parts List	17
Troubleshooting:	
Continuous Fan Sequence of Operation	18
Cooling Sequence of Operation	19
Heating Sequence of Operation	20

Shipping & Packing List

1 - CBWMV Air Handler [NOTE - Includes FreezeStat mounted to the manifold.]

1 - Bag assembly containing:

- 1 - Electrical make-up box
- 1 - Copper fitting
- 1 - Snap bushing
- 2 - Water line grommets
- 3 - Wire nuts
- 2-7/8" cabinet plugs

Check equipment for shipping damage. If you find any damage, immediately contact the last carrier.

09/06



Page 1

505,047M



Lennox air handler manual is an essential resource for homeowners and technicians alike, providing vital information on installation, operation, maintenance, and troubleshooting of Lennox air handlers. These units are integral components of many HVAC systems, affecting overall performance and efficiency. Understanding how to use the manual effectively can enhance the longevity of your air handler and ensure optimal indoor comfort. In this comprehensive guide, we will explore the key elements of the Lennox air handler manual, its components, maintenance tips, troubleshooting steps, and more.

Understanding Lennox Air Handlers

Lennox air handlers are designed to work seamlessly with various heating and cooling

systems. They are responsible for circulating conditioned air throughout your home, making them crucial for maintaining a comfortable living environment. Here are some key features of Lennox air handlers:

- **Energy Efficiency:** Many Lennox models are designed with high-efficiency motors and advanced technology that reduce energy consumption.
- **Variable Speed Technology:** This feature allows the air handler to adjust its airflow based on your home's specific heating and cooling needs, enhancing comfort and efficiency.
- **Quiet Operation:** Lennox air handlers are engineered to operate quietly, providing comfort without disruptive noise.

Components of the Lennox Air Handler

The Lennox air handler consists of several key components, each playing a critical role in its operation. Understanding these components can help you navigate the manual more effectively.

1. Blower Motor

The blower motor is responsible for moving air through the ductwork. Lennox air handlers often feature multi-speed or variable-speed motors to optimize airflow and energy use.

2. Coils

The air handler contains either evaporator coils or a heat exchanger, depending on whether it's part of a cooling or heating system. These coils facilitate heat exchange, cooling the air in summer and heating it in winter.

3. Filter

Air filters are crucial for maintaining indoor air quality. The manual will specify the type of filter needed and the recommended replacement schedule.

4. Drain Pan and Drain Line

The drain pan collects condensation produced during the cooling process. A properly functioning drain line is essential to prevent water damage and ensure efficient operation.

Using the Lennox Air Handler Manual

The Lennox air handler manual is a comprehensive document that provides guidance on various aspects of the unit. Here are some key sections typically included in the manual:

1. Installation Instructions

The installation section provides detailed steps for properly installing the air handler, including:

- Required tools and materials
- Electrical and ductwork connections
- Mounting and leveling the unit

2. Operation Guidelines

This section outlines how to operate the air handler effectively. It covers:

- Thermostat settings
- Fan speed adjustments
- Seasonal operation tips

3. Maintenance Recommendations

Regular maintenance is critical to ensure longevity and efficiency. The manual typically includes:

- Filter replacement schedule
- Coil cleaning instructions

- General maintenance tips

4. Troubleshooting Guide

Should issues arise with your air handler, the troubleshooting section can help diagnose common problems. Some common issues and their potential solutions include:

- **No airflow:** Check for obstructions in the ductwork or issues with the blower motor.
- **Inconsistent temperatures:** Verify thermostat settings and check for dirty filters.
- **Unusual noises:** Inspect for loose parts or debris in the blower assembly.

Maintenance Tips for Your Lennox Air Handler

To keep your Lennox air handler running efficiently, follow these maintenance tips:

1. Regular Filter Changes

One of the simplest yet most effective maintenance tasks is to change the air filter regularly. A clogged filter can restrict airflow and reduce efficiency. Check the manual for specific recommendations on filter types and replacement frequency.

2. Clean the Coils

Dirty coils can significantly impact the performance of your air handler. Schedule regular cleaning to ensure the coils can effectively transfer heat. Use a soft brush or a vacuum to remove dust and debris.

3. Inspect the Drain Line

A clogged drain line can lead to water damage and system failure. Periodically check the drain line for blockages and clear any buildup. Ensure the drain pan is clean and free of debris.

4. Professional Inspections

Consider scheduling annual professional inspections to ensure your air handler operates efficiently. Technicians can identify potential issues before they become significant problems and perform maintenance tasks that are difficult to do on your own.

Conclusion

In conclusion, the **Lennox air handler manual** is an invaluable resource for anyone looking to maximize the efficiency and lifespan of their air handler. By understanding the key components, using the manual effectively, and following maintenance guidelines, you can ensure your heating and cooling system operates at peak performance. Whether you're a homeowner or a technician, familiarizing yourself with the Lennox air handler manual will empower you to take control of your indoor comfort. Always refer to the specific manual for your model for the most accurate and detailed information.

Frequently Asked Questions

Where can I find the Lennox air handler manual for my model?

You can find the Lennox air handler manual for your specific model on the official Lennox website under the 'Support' or 'Resources' section. You can also contact Lennox customer service for assistance.

What are the key maintenance tips outlined in the Lennox air handler manual?

The key maintenance tips typically include regularly changing the air filter, cleaning the drain pan, checking the blower motor, and ensuring that the air handler is free of debris to maintain optimal performance.

How do I troubleshoot common issues with my Lennox air handler as per the manual?

Common issues can often be resolved by checking the power supply, ensuring the thermostat is set correctly, inspecting the air filter for clogs, and listening for unusual noises. The manual provides detailed troubleshooting steps for specific problems.

What safety precautions does the Lennox air handler manual recommend?

The manual recommends turning off power to the air handler before performing any maintenance, ensuring proper grounding, and using personal protective equipment when

handling electrical components.

How often should I refer to the Lennox air handler manual for updates?

It's advisable to refer to the Lennox air handler manual at least once a year, especially before the heating or cooling season, to ensure you're following the latest maintenance guidelines and operating procedures.

Are there any specific installation instructions in the Lennox air handler manual?

Yes, the Lennox air handler manual includes detailed installation instructions, including guidelines on proper placement, ductwork connections, electrical wiring, and setting up the condensate drain to ensure optimal performance.

Find other PDF article:
<https://soc.up.edu.ph/57-chart/Book?dataid=siQ87-4443&title=tai-chi-24-form-step-by-step.pdf>

Lennox Air Handler Manual

Goodman lennox -
Goodman lennox Energy.gov 67
...

LB -
Mar 15, 2016 · LB
out ...

SS...
NaCl LB - Miller LB - Lennox LB - LB
DNA DNA ...

Adam (Adaptive Moment Estimation) -
Adam Adam Adam Adam Adam Adam Adam Adam Adam Adam Adam
...

lb -
lb Lennox broth without salt (LB-NS)
...

Goodman lennox -
Goodman lennox Energy.gov 67
...

LB -

Mar 15, 2016 · LB
out Posted on 2016-01-31 by Ryan ...

SS LB -

NaCl LB - Miller LB - Lennox LB - LB DNA DNA

Adam (Adaptive Moment Estimation) -

Adam RMSProp+ ...

lb -

lb Lennox broth without salt (LB-NS) 2

Find your Lennox air handler manual here for essential maintenance tips and troubleshooting advice. Ensure optimal performance—learn more today!

[Back to Home](#)