

# **2006 Kenworth T800 Fuse Panel Diagram**

	1	2	3	4	5	6	7	8	9	10	11	12
SP												
A	SAT COMM 10A	SPARE BATT B	SPARE BATT C	SPARE BATT D	SPARE BATT E	SPARE BATT F	SPARE BATT G	SPARE BATT H	SPARE ACC A	SPARE ACC B	SPARE ACC C	SPARE ACC D
B	SPARE SW A 15A	SPARE SW B 15A	SPARE SW C 15A	SPARE SW D 20A	CIG LTR 20A	SPARE BATT B	SAT COMM 5A	TRANSMISSION 10A	ALARM 15A	FUEL HTN 30A	CAB ABS 10A*	TRLR ABS 25A*
C	MISC LOW CURR 5A	KEY SW 10A	FLOOD LMPs 15A	FOG LMPs 20A*	HOT LINE 30A	CAB MKR 15A	SIGN LMPs 10A	SPOT LMPs 10A	WIPR PARK 25A	PARK LMPs 30A	RH DOOR 25A*	LH DR DOOR LOCK 25A*
D	PARK LMP SNSE 5A*	TURN MOD PWR 5A*	RADIO MEM 10A*	LEFT TURN/ STOP 30A	RT TURN/ STOP 30A	TRLR STOP 30A	TRLR MKR 30A	GAUGE CL 5A*	RKE 5A*	DR LP/ HORN/ DIAG 10A	MIRR HT 30A	CAB ABS 30A*
E	PARK LAMP RELAY	IGN BUS RELAY		MARKER FLASH RELAY		WIPER HI/LOW RELAY		TRAILER STOP LP RELAY		ABS POWER RELAY		
F	ENG SD 5A*	DOOR 5A*	BU LP AC RELAY 10A	CC FEED 10A*	WARN LMPs 10A	AIR TANK 15A	ENG AUX 15A*	CECU 5A*	CECU 15A*	CECU 15A*	LOW BEAM SUP 20A*	HIGH BEAM SUP 20A*
G	IDLE TIMER RELAY	ACC BUS RELAY		CAB MRKR LP RELAY		WIPER ON RELAY		SLEEPER HVAC RELAY		TRAILER MRKR LP RELAY		
H	CAB DOME LPS 10A	CAB ACC 20A	SLPR DOME LPS 15A	SLPR ACC 30A*	SLPR HT 20A	WIPE/ WASH 25A	RELAY PWR 5A	CB PWR 10A*	RADIO PWR 10A*	HVAC CON 5A	HVAC MOT 30A	BODY IGN 10A*
J	AC CMP CLUTCH RELAY	FLOOD LAMP RELAY	HORN RELAY	REFER LT RELAY	FOG LAMP RELAY	SPARE RELAY #1		SPARE RELAY #2		MIRROR HEAT RELAY		

THIS SECTION  
OF CENTRAL  
ELECTRICAL  
PANEL BEHIND  
INSTRUMENT  
PANEL

**WARNING!**

REFER TO  
OPERATOR  
MANUAL OR  
CONTACT AN  
AUTHORIZED  
KW DEALER,  
PRIOR TO  
SERVICING

THE CIRCUITS  
MARKED WITH  
(\*) MUST BE  
PROTECTED  
WITH FUSE  
ONLY.  
NO CIRCUIT  
BREAKERS.  
SEE OPERATOR  
MANUAL FOR  
DETAILS.

ADDITIONAL  
FUSES FOR  
ELECTRONIC  
ENGINE LOCATED  
IN BATTERY BOX  
OR ENGINE  
COMPARTMENT

SPARE FUSE MAX  
RATING 30 AMPS.

70 AMP RELAYS  
IGNITION BUS  
ACCESSORY BUS



-553-1163

01/14/10 522-1146-410 E 10/10/2010

ASSY 522-1146-410 REV-B

## 2006 Kenworth T800 Fuse Panel Diagram

The 2006 Kenworth T800 is a robust and reliable truck widely used in various commercial applications. One of the critical components that ensure the smooth operation of the vehicle's electrical system is the fuse panel. Understanding the fuse panel diagram for this model is essential for troubleshooting electrical issues, replacing fuses, and ensuring that all electrical components function correctly. In this article, we will delve into the specifics of the 2006 Kenworth T800 fuse panel, including its layout, functions, common issues, and maintenance tips.

## Overview of the Fuse Panel

The fuse panel in the 2006 Kenworth T800 is designed to protect the truck's electrical system by preventing overloads and short circuits. It houses several fuses that control various electrical components and systems. The fuse panel is typically located in the cab of the truck, often near the driver's side, making it accessible for quick inspections and repairs.

## Importance of the Fuse Panel

The fuse panel serves several critical functions, including:

1. Protection: It protects electrical circuits by breaking the connection if the current exceeds a safe level.
2. Organization: It organizes fuses in a way that allows for easy identification and replacement.
3. Troubleshooting: Understanding the fuse panel diagram aids in diagnosing electrical issues effectively.

## Understanding the Fuse Panel Diagram

The fuse panel diagram for the 2006 Kenworth T800 illustrates the layout and function of each fuse within the panel. The diagram typically includes the following information:

- Fuse Numbers: Each fuse is assigned a number for easy reference.
- Fuse Ratings: The amperage rating of each fuse is indicated, which is crucial for selecting the correct replacement.
- Component Names: The diagram specifies which electrical components each fuse controls.

## Common Fuse Ratings and Components

The following are some common fuses found in the 2006 Kenworth T800 fuse panel, along with their typical ratings and the components they protect:

- Fuse 1 (10A): Instrument Panel
- Fuse 2 (15A): Headlights

- Fuse 3 (20A): Turn Signals
- Fuse 4 (15A): Brake Lights
- Fuse 5 (30A): Power Windows
- Fuse 6 (10A): Radio
- Fuse 7 (25A): Wipers
- Fuse 8 (30A): Horn

This list is not exhaustive, and the specific layout may vary based on optional equipment or modifications made to the vehicle.

## Locating the Fuse Panel

To access the fuse panel in the 2006 Kenworth T800, follow these steps:

1. Open the Driver's Door: Ensure that the truck is parked on a level surface and the ignition is off.
2. Locate the Fuse Panel: Depending on the configuration, the fuse panel is typically found on the left side of the dashboard or under the steering wheel.
3. Remove the Cover: If applicable, remove any cover that may be protecting the fuse panel for easier access.

## How to Replace a Fuse

Replacing a blown fuse in the 2006 Kenworth T800 is a straightforward process. Here's how to do it:

1. Identify the Blown Fuse: Refer to the fuse panel diagram to locate the specific fuse associated with the malfunctioning component. A blown fuse will typically have a broken wire or a discolored appearance.
2. Remove the Blown Fuse: Use a fuse puller or pliers to grasp the fuse and pull it straight out of its socket.
3. Install a New Fuse: Select a new fuse that matches the amperage rating of the blown fuse. Insert the new fuse into the same socket, ensuring it is seated correctly.
4. Test the Electrical Component: Turn on the vehicle and test the component to ensure it is functioning properly.

## Tips for Fuse Replacement

- Always use a fuse with the correct amperage rating to prevent damage to the electrical system.
- If a fuse blows shortly after being replaced, it may indicate a deeper electrical issue that requires professional diagnosis.

## Common Electrical Issues and Troubleshooting

Electrical problems in the 2006 Kenworth T800 can often be traced back to issues with the fuse panel or its components. Here are some common issues and troubleshooting steps:

## **1. Blown Fuses**

Symptoms: Malfunctioning lights, non-working accessories, or dashboard warning lights.

Troubleshooting Steps:

- Check the relevant fuse using the diagram.
- Replace any blown fuses and monitor if they blow again.

## **2. Corroded Fuse Connections**

Symptoms: Intermittent electrical problems or flickering lights.

Troubleshooting Steps:

- Inspect the fuse panel for signs of corrosion or damage.
- Clean any corroded connections with electrical contact cleaner.

## **3. Faulty Electrical Components**

Symptoms: Specific components not functioning despite good fuses.

Troubleshooting Steps:

- Test the affected component directly for functionality.
- Check wiring and connectors for damage or loose connections.

## **Maintenance Tips for the Fuse Panel**

Regular maintenance of the fuse panel can help prevent electrical issues and extend the life of the truck's electrical system. Here are some maintenance tips:

1. Regular Inspections: Periodically check the fuse panel for any signs of wear, damage, or corrosion.
2. Clean Connections: Use electrical cleaner to keep connections free of dirt and corrosion.
3. Keep Spare Fuses: Have spare fuses on hand for quick replacements when necessary.
4. Consult the Manual: Refer to the owner's manual for specific maintenance recommendations related to the electrical system.

# Conclusion

Understanding the 2006 Kenworth T800 fuse panel diagram is crucial for any truck owner or operator. By familiarizing yourself with the fuse panel's layout, components, and maintenance practices, you can ensure the reliable operation of your vehicle's electrical system. Regular inspections and timely fuse replacements can prevent minor issues from escalating into significant problems, ultimately keeping your truck on the road and operating efficiently.

## Frequently Asked Questions

### **What is the location of the fuse panel in a 2006 Kenworth T800?**

The fuse panel in a 2006 Kenworth T800 is typically located under the dashboard on the driver's side, near the steering column.

### **Where can I find a detailed fuse panel diagram for a 2006 Kenworth T800?**

A detailed fuse panel diagram for a 2006 Kenworth T800 can usually be found in the vehicle's owner manual or service manual. You can also find diagrams online through truck forums and repair websites.

### **What are common issues that can be diagnosed using the fuse panel diagram of a 2006 Kenworth T800?**

Common issues include non-functioning lights, malfunctioning accessories, or problems with the ignition system, which can often be traced back to blown fuses as indicated in the fuse panel diagram.

### **How can I identify a blown fuse in the fuse panel of a 2006 Kenworth T800?**

You can identify a blown fuse by visually inspecting it for a broken wire inside the fuse or by using a multimeter to test for continuity. The fuse panel diagram will indicate which fuses correspond to specific systems.

### **Are there any specific fuses in the 2006 Kenworth T800 that are prone to failure?**

Yes, fuses related to the lighting system and electronic accessories are often more prone to failure due to higher usage, so it's advisable to keep an eye on them.

### **Can I replace a fuse in a 2006 Kenworth T800 with a higher**



